

How To Install Privacy Picket Panels

Our privacy slats can be used for either 100 percent privacy, or turn them 90° to guide air into your fenced area. Installing these privacy slats is fast and easy.

Required Tools: To cut and install your panels, you will need a miter saw or band saw and a rubber mallet.

Step 1 : Cut the panels, and optional extender dips and locks

Measure the length of your pickets from the bottom of your channel to the top of your bottom channel. This will give you a dimension to start cutting your pickets. We recommend cutting 1/4" shorter than your measurement. This will allow for expansion.

Step 2: Snap the panels onto the fence

Pry open the top of the privacy panel with your fingers. Line it up with the fence picket and snap on. Use the rubber mallet to tap the panel into place, making sure it's secure all the way down.

Step 3 (If you are using extender clips): Secure Clips

Take an extender clip, start from the top and slide down the privacy panel. This will line right up and lock in place.

