

CART INSTALLATION INSTRUCTIONS

Parts List

- 2 1 ½” Square Tube U’s
- 2 1 ½” Square Tube Side Tubes 54” Long
- 4 1 ½” Square Tube Upright Posts
- 2 1” Square Tube Tongue Pieces
- 2 Triangular Tongue Plates
- 2 U Mounts for Tongue
- 4 Wheel Mount Trailer Post Brack

Assembling a SportPanel® Cart

- 1) Slide 1½” Square Tube 22½” long into the Front and Back Trailer Frame U’s to form the trailer frame.
- 2) Assemble Tongue by placing 1” tubes between Triangular Tongue Plates, running 4 bolts through provided holes. Fasten with ¼” x 1½” Bolt and 1 K Lock Washer each.
- 3) Attach the two U Brackets, with open end down, loosely to the front 1½” U by dropping one ¼” Hex Bolt down through hole provided in each end. Attach with one ¼” K Lock Nut.
- 4) Slide ends of tongue into U Mounts and attach with ¼” x 2” Bolts and K Lock Nuts.
- 5) Tighten the ¼” Bolts holding the Tongue Brackets to the front of the trailer.
- 6) Place the 4 Wheel Brackets over the 1½” side U’s, approximately 1 inch from the end of the bend.
- 7) Bolt Wheels to Wheel Brackets, being sure that the two castor wheels are located at the front of the wagon. Use 4 5/16” Bolts, Nuts, and Washer for each wheel.
- 8) Shoot self-tapping sheet metal screws into the side U’s approximately one inch from where the end posts and the side U’s form a joint.
- 9) Stand 42” Side Posts in the Wheel Bracket Sockets.

We thank you for choosing SportPanel for your outfield fencing needs, the world’s #1 selling outfield fence.